



TORCUP

SQ-10 Torque Conversion Chart

Imperial Conversion		Metric Conversion	
PSI	ft-lb	Bar	Nm
1,000	945	69	1281
1,200	1150	83	1559
1,400	1354	97	1836
1,600	1559	110	2114
1,800	1763	124	2390
2,000	1968	138	2668
2,200	2179	152	2954
2,400	2389	165	3239
2,600	2600	179	3525
2,800	2810	193	3810
3,000	3021	207	4096
3,200	3234	221	4385
3,400	3446	234	4672
3,600	3659	248	4961
3,800	3871	262	5248
4,000	4084	276	5537
4,200	4300	290	5830
4,400	4517	303	6124
4,600	4733	317	6417
4,800	4950	331	6711
5,000	5166	345	7004
5,200	5382	359	7297
5,400	5599	372	7591
5,600	5815	386	7884
5,800	6032	400	8178
6,000	6248	414	8471
6,200	6466	427	8767
6,400	6684	441	9062
6,600	6901	455	9356
6,800	7119	469	9652
7,000	7337	483	9948
7,200	7560	496	10250
7,400	7783	510	10552
7,600	8006	524	10855
7,800	8229	538	11157
8,000	8452	552	11459
8,200	8673	565	11759
8,400	8894	579	12059
8,600	9114	593	12357
8,800	9335	607	12657
9,000	9556	621	12956
9,200	9775	634	13253
9,400	9994	648	13550
9,600	10212	662	13846
9,800	10431	676	14143
10,000	10650	689	14439

For reference purposes only, please consult the calibration chart specific to your purchase or rental tool.

TorcUP, Inc.
1025 Conroy Place
Easton, Pa 18040

Tel:610-250-5800 Fax: 610-250-2700

