



TORCUP

TU-20 Torque Conversion Chart

Imperial Conversion	
PSI	Ft-lbs
1,000	2249
1,200	2683
1,400	3118
1,600	3552
1,800	3987
2,000	4421
2,200	4847
2,400	5273
2,600	5700
2,800	6126
3,000	6552
3,200	6974
3,400	7396
3,600	7818
3,800	8240
4,000	8662
4,200	9077
4,400	9492
4,600	9906
4,800	10321
5,000	10736
5,200	11158
5,400	11580
5,600	12002
5,800	12424
6,000	12846
6,200	13271
6,400	13696
6,600	14120
6,800	14545
7,000	14970
7,200	15388
7,400	15806
7,600	16223
7,800	16641
8,000	17059
8,200	17492
8,400	17925
8,600	18357
8,800	18790
9,000	19223
9,200	19653
9,400	20082
9,600	20512
9,800	20941
10,000	21371

Metric Conversion	
Bar	Nm
69	3049
83	3638
97	4227
110	4816
124	5405
138	5994
152	6572
165	7150
179	7728
193	8305
207	8883
221	9455
234	10028
248	10600
262	11172
276	11744
290	12306
303	12869
317	13431
331	13994
345	14556
359	15128
372	15700
386	16273
400	16845
414	17417
427	17993
441	18569
455	19145
469	19721
483	20297
496	20863
510	21430
524	21996
538	22562
552	23129
565	23716
579	24302
593	24889
607	25476
621	26063
634	26645
648	27228
662	27810
676	28393
689	28975

For reference purposes only, please consult the calibration chart specific to your purchase or rental tool.

TorcUP, Inc.
1025 Conroy Place
Easton, Pa 18040

Tel:610-250-5800 Fax: 610-250-2700

