



TORCUP

TU-27 Torque Conversion Chart

Imperial Conversion		Metric Conversion	
PSI	Ft-lbs	Bar	Nm
1,000	3032	69	4111
1,200	3606	83	4889
1,400	4180	97	5668
1,600	4755	110	6446
1,800	5329	124	7225
2,000	5903	138	8003
2,200	6469	152	8771
2,400	7035	165	9538
2,600	7600	179	10305
2,800	8166	193	11072
3,000	8732	207	11839
3,200	9302	221	12612
3,400	9873	234	13386
3,600	10443	248	14159
3,800	11014	262	14932
4,000	11584	276	15706
4,200	12137	290	16455
4,400	12690	303	17205
4,600	13242	317	17954
4,800	13795	331	18704
5,000	14348	345	19453
5,200	14911	359	20217
5,400	15474	372	20980
5,600	16037	386	21743
5,800	16600	400	22507
6,000	17163	414	23270
6,200	17720	427	24026
6,400	18278	441	24781
6,600	18835	455	25537
6,800	19393	469	26293
7,000	19950	483	27049
7,200	20510	496	27807
7,400	21069	510	28566
7,600	21629	524	29325
7,800	22188	538	30083
8,000	22748	552	30842
8,200	23308	565	31601
8,400	23868	579	32360
8,600	24427	593	33119
8,800	24987	607	33878
9,000	25547	621	34637
9,200	26106	634	35395
9,400	26665	648	36153
9,600	27225	662	36912
9,800	27784	676	37670
10,000	28343	689	38428

For reference purposes only, please consult the calibration chart specific to your purchase or rental tool.

TorcUP, Inc.
1025 Conroy Place
Easton, Pa 18040

Tel:610-250-5800 Fax: 610-250-2700

